



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

ES-1303: EYE SHADOW WITH MICROEASE 114S (Efficient Binding with Creamy Aesthetics)			
INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Sericite PHN	Mica	30.75	Presperse
Microease 114S	Synthetic Wax	7.00	Micro Powders, Inc.
Rose Talc	Talc	40.00	Presperse
Zinc Laurate Z-12	Zinc Laurate	2.00	Ikeda
Luxsil®	Calcium Aluminum Borosilicate	2.00	Presperse
Pearl II	Bismuth Oxychloride	1.00	Presperse
Black Iron Oxide 7133	Iron Oxide	9.00	Sensient Colors LLC
Optiphen OD	Caprylyl Glycol	0.50	Ashland LLC
Optiphen PO	Phenoxyethanol	0.25	Ashland LLC
Phase B			
Permethyl® 102A	Isoeicosane	3.00	Presperse
PEG-4 Dilaurate	PEG-4 Dilaurate	4.00	N/A
Crill 6	Sorbitan Isostearate	0.50	Croda
	Total	100%	
Procedure			
<ol style="list-style-type: none">1. Combine ingredients of Phase A.2. Mix well using a ribbon type blender.3. Pass through a micropulverizer until uniformly pulverized.4. Pre-mix Phase B ingredients, then spray into Phase A.5. Mix well again into uniformity.6. Press at 1500 Psi in an appropriate container.			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 www.mpipersonalcare.com			