



MICRO POWDERS, INC.

Specialty Micronized Wax Additives

LP-1603: LOOSE FACE POWDER WITH MICROPOLY 250S (Creamy Aesthetics with Soft Focus)

INGREDIENT	INCI NAME	% W/W	SUPPLIER
Phase A			
Sericite PHN	Mica	90.39	Presperse
SM-1000	Mica (&) Silica	1.00	Presperse
SP-29 UVS	Bismuth Oxychloride/ Silica/Mica	1.00	Presperse
Micropoly® 250S	Polyethylene	6.00	Micro Powders, Inc.
Yellow Iron Oxide 7055	Iron Oxide	0.25	Sensient Colors LLC
Red Iron Oxide 7080	Iron Oxide	0.25	Sensient Colors LLC
Brown Iron Oxide C33-5136	Iron Oxide	0.04	Sun Chemical
Black Iron Oxide 7133	Iron Oxide	0.02	Warner Jenkinson
BarGuard™ S	Caprylyl Glycol, Phenoxyethanol & Sorbic Acid	0.55	Hampford Research Inc.
Phase B			
Panthanol	Panthanol	0.50	Lotioncrafter
	Total	100%	

Procedure

1. Combine ingredients of Phase A in a ribbon type blender.
2. Pass through a micropulverizer until uniformly blended and mixed.
3. Add Phase B ingredient and blend well until evenly dispersed.