



# MICRO POWDERS, INC.

Specialty Micronized Wax Additives

<b>SCR-1908: BODY SCRUB WITH SYNSCRUB 1435PC</b> ( Look and Feel of Salt/Sugar Scrubs with Longer-Lasting Effect )			
<b>INGREDIENT</b>	<b>INCI NAME</b>	<b>% W/W</b>	<b>SUPPLIER</b>
<b>Phase A</b>			
Deionized Water	Water	41.60	N/A
Glycerine	Glycerine	3.00	Lotion Crafter
Protachem NA2-P	Disodium EDTA	0.10	Protameen Chemicals Inc.
Butylene Glycol	Butylene Glycol	3.00	Lotion Crafter
Triethanolamine 99%	Triethanolamine	0.80	N/A
Optiphen PO	Phenoxyethanol	0.50	Ashland Inc.
<b>Phase B</b>			
Carbopol 980, 1.2% Aq solution with 0.5% Phenoxyethanol	Water, Carbomer & Phenoxyethanol	44.00	Lubrizol - Carbopol and Ashland - Phenoxyethanol
<b>Phase C</b>			
SD Alcohol 40-B	Ethyl Alcohol Denatured	2.00	N/A
<b>Phase D</b>			
<b>Synscrub 1435PC</b>	Synthetic Wax	5.00	<b>Micro Powders, Inc.</b>
	<b>Total</b>	<b>100%</b>	
<b>Procedure</b>			
<ol style="list-style-type: none"><li>1. Weigh all Phase A ingredients into a beaker. Start mixing using propeller blade at slow to medium speed until it is uniform and clear.</li><li>2. Slowly add Phase B under medium mixing. As the batch starts to thicken, switch to sweep agitation. Continue to mix until homogeneous.</li><li>3. Add Phase C and continue to mix slowly until uniformly dispersed.</li><li>4. Add Phase D to Phase A+B+C. Mix until homogeneous.</li></ol>			
Micro Powders, Inc. 580 White Plains Road, Tarrytown, NY 10591 Tel: (914) 793-4058 Fax: (914) 472-7098 <a href="http://www.mpipersonalcare.com">www.mpipersonalcare.com</a>			